



Party Launcher Operating Instructions

Follow these safety precautions when using confetti effect launching equipment:

1. Read all instructions.
2. Inspect the device prior to each use for cracks or damaged areas.
3. Position the launchers so they will not launch confetti or streamer product directly at anyone, into mechanical equipment, onto hot devices such as lighting equipment or into centerpiece candles.

Normal operating procedures:

1. Load the Handheld Confetti Launcher with approved confetti or streamer products. Check that the barrel is free of obstacles. Remove the cap from the "load" and transfer the contents into the barrel. Be careful not to drop packaging into the barrel.
 2. Cap the barrel by placing the paper cap over the end of the barrel and wrapping a single layer of masking tape around the sides, securing the cap to the barrel. Do not tape over the end.
 3. Screw-in the 16-gram threaded CO₂ bottle into the black holder on the handle and screw the cup to the piercing connector. When the attached string is pulled, it will pierce the Use caution! The launcher is now loaded and charged.
 4. Consider the area 25' in front of the direction of the launcher to be the "launching zone." Clear the launching zone directly in front of the opening.
 5. Hold the barrel in one hand and aim the launcher. Quickly pull the string with just enough force to pierce the valve without changing the direction of the aim of the barrel.
 6. Check to be sure all discharged launchers have been operated fully and there is no remains. A launcher that is not to be operated should be disconnected from the CO₂ canister.
- Look in our schedule of streamers and confetti for speed load tubes. These are quick, easy and have much more product than bulk loads. Bulk loads are not capable of going as far, due to looseness of material.
 - For shorter distance, do not cap the barrel. For longer distance, use push cups in the bottom before loading the confetti.