


Unpacking SnoBiz® rev 1208

Congratulations on purchasing SnoBiz®, the closest looking thing to real snow. This product dissolves when wet; therefore it is very important to unpack it in a dry area. The large bag inside should not be cut. Use caution when using a sharp instrument to cut the tape, being careful not to penetrate to the plastic bag inside.

Here are a few tips on unpacking SnoBiz® so you may create a wonderful snow effect. Each bag holds 5 pounds of snow, which expands to 10 cubic feet. The product has been vacuum packed for shipping and will have some clumps. For best results, pull the plastic bag completely out of the box to fluff the snow. Unfold the large bag and shake contents to loosen, being careful to hold the end of the bag closed. It is also helpful to push against the bag to break up any large clumps. The large bag allows the product plenty of room to continue to loosen.



While holding the end of the bag closed, let air out as you push on the sides of the bag. This allows you to loosen the clumps without having the snow leave the bag.

After loosening snow, shake the bag and stick your hands inside to fluff, allowing air to enter. Each snow particle will expand slowly. Stand the bag in a corner and allow it to stand at least one hour before use, overnight if possible, for more expansion of the particles. SnoBiz® should expand to more than 3 times the box size and particles will become much larger, giving more of the appearance of snowflakes. Allowing expansion of the product also helps in making it fluffy, float longer without spinning through the air and will look more like falling snowflakes.



Note: the clumps could be used as snowballs for snow fight scenes where the snow falls apart on impact. If desired, pull out a few clumps for such use, shape them and hold them aside.


For best results, shoot SnoBiz® through CITC's Shot Max to break smaller clumps and separate the snow. The Shot Max not only separates any clumps that may be left, but also shoots the product up and out up to 25'. The Shot Max is excellent for shooting SnoBiz in front of a large fan or away from you. It can also be used to force the snow into a windbag for distribution over a long extended stage area.

SnoBiz® is made from rice and wheat gluten, without any preservatives, diglycerides or monoglycerides. This product is completely safe for the environment. Fish and stream safety data is available upon request. SnoBiz® is not potato flakes and does not have the preservatives associated with other types of biodegradable packing materials. The product is extruded for expansion before it is ground, sifted and packaged.

Unpacking SnoBiz® rev 1208


Congratulations on purchasing SnoBiz®, the closest looking thing to real snow. This product dissolves when wet; therefore it is very important to unpack it in a dry area. The large bag inside should not be cut. Use caution when using a sharp instrument to cut the tape, being careful not to penetrate to the plastic bag inside.

Here are a few tips on unpacking SnoBiz® so you may create a wonderful snow effect. Each bag holds 5 pounds of snow, which expands to 10 cubic feet. The product has been vacuum packed for shipping and will have some clumps. For best results, pull the plastic bag completely out of the box to fluff the snow. Unfold the large bag and shake contents to loosen, being careful to hold the end of the bag closed. It is also helpful to push against the bag to break up any large clumps. The large bag allows the product plenty of room to continue to loosen.



While holding the end of the bag closed, let air out as you push on the sides of the bag. This allows you to loosen the clumps without having the snow leave the bag.

After loosening snow, shake the bag and stick your hands inside to fluff, allowing air to enter. Each snow particle will expand slowly. Stand the bag in a corner and allow it to stand at least one hour before use, overnight if possible, for more expansion of the particles. SnoBiz® should expand to more than 3 times the box size and particles will become much larger, giving more of the appearance of snowflakes. Allowing expansion of the product also helps in making it fluffy, float longer without spinning through the air and will look more like falling snowflakes.



Note: the clumps could be used as snowballs for snow fight scenes where the snow falls apart on impact. If desired, pull out a few clumps for such use, shape them and hold them aside.

For best results, shoot SnoBiz® through CITC's Shot Max to break up smaller clumps and separate the snow. The Shot Max not only separates any clumps that may be left, but also shoots the product up and out up to 25'. The Shot Max is excellent for shooting SnoBiz in front of a large fan or away from you. It can also be used to force the snow into a windbag for distribution over a long extended stage area.

SnoBiz® is made from rice and wheat gluten, without any preservatives, diglycerides or monoglycerides. This product is completely safe for the environment. Fish and stream safety data is available upon request. SnoBiz® is not potato flakes and does not have the preservatives associated with other types of biodegradable packing materials. The product is extruded for expansion before it is ground, sifted and packaged.

Because SnoBiz® is a water-soluble product, it tends to absorb water content, even in high humidity. The product will become heavier if allowed to absorb very humid air, causing it to fall more quickly. In situations where you want to have the snow lay on the ground, increased humidity will help. For applications where you want it to stick to the leaves or pine needles of a tree, moisten the area with a light spray of water before applying.

Where a frozen look is desired, lightly spray the surface with a very fine mist, then sprinkle or blow fine SnoBiz® over it. You can write in it with your fingers, like real frost.

Because SnoBiz® is made from food grade product, it will not harm you if accidentally eaten or swallowed in small amounts. However, this product is not for human consumption and should not be used as such.

CLEAN UP: Always place the product in a dry area because SnoBiz® becomes sticky when wet and contact with wet items will cause it to stick to them. To remove, rake most of the bulk, then soak the remaining product in copious amounts of water. Soak longer or use extra water if necessary.

Any questions concerning SnoBiz® should be directed to:



1420 80th St. SW #D, Everett, WA 98203
(425) 776-4950 ♦ (888) 786-CITC ♦ FAX: (425) 776-5129
www.citcfx.com ♦ info@citcfx.com
SnoBiz® is a registered Trademark of CITC



12/04/2008

Because SnoBiz® is a water-soluble product, it tends to absorb water content, even in high humidity. The product will become heavier if allowed to absorb very humid air, causing it to fall more quickly. In situations where you want to have the snow lay on the ground, increased humidity will help. For applications where you want it to stick to the leaves or pine needles of a tree, moisten the area with a light spray of water before applying.

Where a frozen look is desired, lightly spray the surface with a very fine mist, then sprinkle or blow fine SnoBiz® over it. You can write in it with your fingers, like real frost.

Because SnoBiz® is made from food grade product, it will not harm you if accidentally eaten or swallowed in small amounts. However, this product is not for human consumption and should not be used as such.

CLEAN UP: Always place the product in a dry area because SnoBiz® becomes sticky when wet and contact with wet items will cause it to stick to them. To remove, rake most of the bulk, then soak the remaining product in copious amounts of water. Soak longer or use extra water if necessary.

Any questions concerning SnoBiz® should be directed to:



1420 80th St. SW #D, Everett, WA 98203
(425) 776-4950 ♦ (888) 786-CITC ♦ FAX: (425) 776-5129
www.citcfx.com ♦ info@citcfx.com
SnoBiz® is a registered Trademark of CITC



12/04/2008